Blue mr Handsfree®

TabCover

AZERTY

USER'S MANUAL

GB NL FR E

WWW · MRHANDSFREE · COM

DECLARATION OF CONFORMITY

Hereby,

Company	TE-Group NV
Address:	Kapelsestraat 61, 2950 Kapellen, Belgium

Declares that

Product Name	mr Handsfree Blue TabCover
Product Type	Bluetooth® keyboard + protective case

is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The product has been tested against the followings standards and specifications, applying versions valid in November, 2012:

EN 301489-1

EN 301489-17

EN 300328

EN 60950-1

Joseph van Oosterum, CEO TE-Group NV, 12-11-2012

CE

PARTS AND FUNCTIONS



CHARGING THE AZERTY KEYBOARD

The AZERTY keyboard can be charged using the supplied USB to micro-USB charging cable. Connect the micro-USB end of the supplied cable into the AZERTY keyboard.
Connect the other end of the USB cable to your laptop/computer or any other USB charging device. During charging, the red LED indicator will light. When the battery is fully charged, the LED indicator will turn off.
Note: When the blue LED indicator is flashing quickly, the battery is almost empty. Please charge it ASAP.

TURNING ON / PAIRING THE AZERTY KEYBOARD

Turn on the AZERTY keyboard with the power ON/OFF switch on the right side.



Press the Pairing button located in the right bottom corner of the AZERTY keyboard to start the Bluetooth® pairing process. The blue LED indicator will start flashing.



GB

Select the "Settings" icon on your Samsung GalaxyTab® screen, then select "Bluetooth®" and turn "Bluetooth®" to ON.

Your Samsung GalaxyTab® will search for available Bluetooth® devices. Select "MHF TAB-Cover" from the Devices list: at this point, your Samsung GalaxyTab® will display a pop-up message indicating the pairing code.



Enter this code followed by the "Enter" key using the AZERTY keyboard.

Your AZERTY keyboard is now paired and connected with the tablet. The blue LED pairing indicator will now turn off.

The AZERTY keyboard will enter into battery-saving sleep mode after 30 minutes of inactivity. To activate the keyboard again, press any button, and wait while the connection is being restored.

INSTALLING THE AZERTY KEYBOARD

Go back to the "Settings" screen and scroll down to the "Personal" tab. Click "Language and input" and open the Settings menu of the Samsung keyboard.



From the list that appears when clicking "Input language" choose "Français (France)".

The Bluetooth® AZERTY keyboard can now be used with all text-based applications for Samsung GalaxyTab®.

To select special characters or language accent marks, you should keep the "Alt-GR" key pressed while pressing the key that you would normally press on a standard European AZERTY keyboard. For example, "Alt-GR"+"2"= @ or "Alt GR"+"!" = ~ or "Alt GR" + "e" = €

SPECIAL GALAXYTAB® FUNCTION BUTTONS

1. Home/Escape
2. Luminance –
3. Luminance +
4. E-mail
5. Search
6. Select all*
7. Copy
8. Paste
9. Cut
10. Stop
11. Play/pause
12. Previous track
13. Next track
14. Mute
15. Volume –
16. Volume +
17. Lock Screen

* This function is not supported by all models. If this button does not work, you can use "Ctrl"+"Q" to select all.

GB

CUSTOMER SUPPORT

For all product related questions, please contact: support@mrhandsfree.com.

BLUETOOTH®

The Bluetooth® word mark and logos are owned by the Bluetooth® SIG, Inc. and any use of such marks by TE-Group NV is under license. Other trademarks and trade names are those of their respective owners.

DISPOSAL

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.

GUARANTEE

Copyright © mr Handsfree. Mr Handsfree is a registered trademark of TE-Group NV. The mr Handsfree brand stands for superior product quality and outstanding customer service. That is why mr Handsfree warrants this product against all defects in material and workmanship for a period of **two (2) years** from the date of original purchase of the product. The conditions of this guarantee and the extent of responsibility of mr Handsfree under this guarantee can be downloaded from our website: www.mrhandsfree.com.